

<b>ADR</b>	<b>HEXADR</b>	<b>NAME</b>	<b>Description</b>	<b>shadow</b>	<b>OS</b>
97,98	\$0061,\$0062	NEWCOL		none	A

Point (column) to which DRAWTO and XIO 18 (FILL) will go. [NEWROW](#) and [NEWCOL](#) are initialized to the values in [ROWCRS](#) and [COLCRS](#) (84 to 86; \$54 to \$56) above, which represent the destination end point of the DRAW and FILL functions. This is done so that [ROWCRS](#) and [COLCRS](#) can be altered during these routines.