

ADR	HEXADR	NAME	Description	shadow of	OS
635	\$027B	STICK3	Joystick 4	<a href="#">PORTB</a>	A

This denotes the direction of Joystick 4, where 15 means "centered". It is the higher nibble of [PORTB](#) 54017 \$d301. Joystick 4 is only available on ATARI 400/800 machines. In XL and XE OS's this register has the same content as [STICK1](#).

dec	left		right
up	10	14	6
	11	15	7
down	9	13	5

hex	left		right
up	\$0A	\$0E	\$06
	\$0B	\$0F	\$07
down	\$09	\$0D	\$05

bin	left		right
up	1010	1110	0110
	1011	1111	0111
down	1001	1101	0101

see also [Controller topics](#)

previous: [Joystick 3](#)